

IME-1100U Mifare & EM Encoder

Features



- Supports to read EM (125KHz) card and Mifare (13.56MHz) card.
- Read and write Mifare contactless IC card that complies with ISO 14443A
- Simple & friendly GUI interface software included.
- IME-1100U supports USB HID interface, easy to use and no need to install driver.
- USB bus powered, no need extra power supply.
- It operates in terminal mode, and commands can be issued directly in the terminal.
- Watchdog function secures system free from halting.

Ordering Information

Package Content:

- Encoder x 1
- Quick Start Guide x 1
- Cable x 1
- Software CD x 1

Specifications

Model No.	IME-1100U
Read Format	EM (125KHz) & Mifare (13.56 MHz)
Comm. Interface	USB
Read Range	Mifare: 4cm above (Excluding card data writing) EM: 4cm above
LED Indicator	Status LED (Green / Red) x 1
Beep Tone	Buzzer
Power Input	USB bus powered
Current Consumption	100mA (max.)
Operating Temp.	-20°C ~ 70°C
Relative Humidity	20% ~ 80% (Non-condensing)
Dimension(mm)	110 (L) x 80 (W) x 23 (H)